

# Quick Guide

This printer package contains,  
 SMART Series ID Card Printer / Power Adaptor / Power Cord / USB Cable  
 Ribbon Cartridge (Included in Printer) / Quick Guide (This document)  
 Software Installation CD (Printer Driver / Card Issuance Software / User Manual)

## I. Printer Installation Process

<b>STEP 01</b> Open the top cover of Printer by pressing indicated point.	<b>STEP 02</b> Take out the empty ribbon cartridge.	<b>STEP 03</b> Prepare the ribbon and the ribbon cartridge.	<b>STEP 04</b> Install supply core and take-up core to the holes and press the opposite sides until they click.	<b>STEP 05</b> Install a disposable cleaning roller in the ribbon cartridge.
<b>STEP 06</b> Peel the protective film off on the disposable cleaning roller.	<b>STEP 07</b> Install the ribbon cartridge.	<b>STEP 08</b> Close the top cover of Printer by pressing indicated point.	<b>STEP 09</b> Open the hopper cover and load blank cards.	<b>STEP 10</b> Connect the power cord and USB cable.

## II. Printer Driver Installation Process

<b>STEP 01</b> Insert the installation CD into the PC.	<b>STEP 02</b> Choose the language and click "Driver Install" button.	<b>STEP 03</b> When "User Account Control" window is opened, click "Yes".	<b>STEP 04</b> Choose "Language" and click "Next" in STEP 1. This step may take a few moments.	<b>STEP 05</b> Click "Next" to install the printer driver package in STEP 2.
<b>STEP 06</b> Connect the USB cable to PC and turn on the printer by switching the power on/off button at the indicated point.	<b>STEP 07</b> In case of USB connection, click "Next" and move to STEP 09. Or in case of Network connection, move to STEP 08.	<b>STEP 08</b> Search SMART Series printer connected on the network. Click "OK" after selecting and click "Next". If the printer is not found, Please configure network setting by referring to "SMART User Manual".	<b>STEP 09</b> Click "Close" after installation is completed.	<b>STEP 10</b> Open "Devices and Printers". Right click on "IDP SMART Series Card Printer" and select "Printer Properties".
<b>STEP 11</b> Select the "General" tab and click "Print Test Page" to print Test card.	<b>STEP 12</b> Check the printed status of the printed Test card.			